


Dimensions



FRONT

SIDE

Items	Submenu	BC1080VIR30
CMOS	Device	1/3" 2MEGA CMOS
	Total	2010 (H) x 1108(V)
	Effective	1944 (H) x 1092(V)
Performance	Resolution	Digital : 1080P(30p) , 720P(60P) Max : 1,100TV lines(1080P)
	Scanning system	Progressive
	Minimum illumination(F1.2)	Color : 0.1Lux(50IRE) B/W : 0.08Lux(50IRE)
	S/N Ratio	More than 50dB (AGC off)
	OSD	English/Japanese/German/Italian Russian/Spanish/Chinese/Portuguese
Functions	Day&Night	Auto/Day/B&W/EXT1/EXT2
	ATW	1800 ~ 10500K
	High Speed Shutter	1/30(1/25) ~ 1/60Ksec
	WDR	2 ~ 4
	D-WDR	Off/ON
	BLC	Off/ON (Size, Position)
	HLC	Level Setting(0~20), Color
	AGC	Level Setting(0~10)
	D-Zoom	0~96 Steps
	Camera ID	Off/On (Letters A to Z, Numerals 0 to 9, Symbols)
	White Balance	AUTO / AUTOext / PUSH / MANUAL
	DNR	3DNR, OFF/LOW/MIDDLE/HIGH
	Motion Detection	Off/ON
	Privacy Mask	32 Areas (On/Off, Color, Position)
	Sens-Up	x2 ~ x4
Etc. Function	Sharpness, Reverse(H,V)	Etc. Function
	ColorBar	Off/ON
	In/Output	Alarm Output
Video Output	ANALOGUE	NTSC, PAL CVBS(without WDR)
	HD-SDI(SMA CONNECTOR)	Video Output
Visible Range (LED On)	Indoor	Built-In 30pcs of Super IR Leds(40M)
	Outdoor	Built-In 30pcs of Super IR Leds(30M)
Hardware	Lens	6~50mm DC Auto IRIS VF Lens
	Power Consumption	DC 12V/ 24 AC, Less than 2.2Watts
	Operating Temperature	Absolute : - 10C ~ +50C
	Operating Humidity	Less than 90%
	Dimension	140mm (W) x 190mm (H) x 280mm(W)
	Weight	2200g

*** Above specifications can be subject to change without previous notice***




BC1080VIR30



User Manual

talossecurity.com


Camera installation



Camera setting

1. On the ceiling(or wall), make the Anchor hole and put the Anchor into the hole completely.
Use Fixing Screw to settle (Anchor size : $\Phi 4$ / Length 30mm)
2. After set up the Bracket Base, use "L" wrench to make tight the Camera Body and Bracket Head

Camera setting



1. Open the front cover for adjustment of desired viewing angle and it can be controlled by using the Focus/Zoom control stick like as [PIC 2]
2. According to [PIC 2], open the front cover to SETUP the OSD menu by using Joystick.
3. If necessary, change OSD setting for desired performance, at camera control panel
 - * The extra video output can be used for installation with the Portable monitor.(For the camera setting, please check the OSD menu)
 - * Push the OSD joystick little more than 1sec., OSD manu will be appeared.
 - * Move the OSD joystick to change the setting.
 - * Push the OSD joystick to Enter and Set the menu.
4. After changing OSD menu, lock the front cover completely for weatherproof.